

WELCOME TO THE YO DABBA DABBA FAMILY

PLEASE READ THROUGH THIS MANUAL
BEFORE ASSEMBLING AND ENJOYING YOUR
NEW ELECTRONIC NAIL. WE ARE HERE TO
HELP WITH ANY QUESTIONS YOU MAY HAVE.

For more information visit:



[YoDabbaDabba.com](https://yodabbadabba.com)



[Youtube.com/yodabbadabba](https://youtube.com/yodabbadabba)



[@YoDabbaDabbaTools](https://instagram.com/yodabbadabbatools)

YODABBADABBA.COM

602.753.2222

 @YODABBADABBATOOLS



MINI
TITANIUM

ENAIL USER MANUAL



YO DABBA DABBA

WHAT'S IN THE BOX

- A. POWER CORD
- B. 20MM HEATING COIL
- C. 6-N-1 NAIL
- D. CARB CAP
- E. CONTROL BOX




DO:

- Ensure the coil is secure before use.
- Keep the coil and unit away from liquids.
- Allow the coil to fully cool, naturally, before handling or storing.
- Only use compatible Yo Dabba Dabba accessories.
- Keep away from children and pets.
- Know your state laws.
- Grip the coil at the base when removing from the unit.

DON'T:

- Do not use the coil near fabrics or paper products.
- Do not modify the control box.
- Do not twist, stretch or try to manipulate the heating coil cord.
- Do not leave the unit powered on for extended periods of more than 2 hours.
- Do not leave the unit on unattended.
- Do not leave the carb cap on the nail while the heating coil is attached.
- Do not attempt to clean the unit while powered on.
- Do not operate around volatile or flammable materials.



LOW TEMP: 550-600°F

HIGH TEMP: 750°F+

***Do not exceed 900°F**

***NOTE:** Due to environmental conditions the temperature between the coil and nail can vary by 100 degrees.

AUTO SHUT OFF:

The default auto-shutoff time is 2 hours. To modify, press the middle button on the control box 5 times and use the up and down arrows to adjust the time from 0-5. Setting the number to 0 will turn off the function, and 5 will turn the unit off after five hours.

CAUTION:

This unit is a fire hazard, please operate with extreme caution. The coil is capable of reaching upwards of 1,000°F and can cause serious injury and burns, or permanently damage property. Never leave on or unattended.

TROUBLESHOOTING:

If the display box reads 'E44' there's an issue with the coil. A new coil will resume proper function.

MAINTENANCE:

Check out our FAQ Page for tips on routine maintenance and more information.

yodabbadabba.com/dabbling-resources/enail-faq

REGISTER:

Fill out this quick form to streamline any warranty claims and receive a sticker pack from us!

yodabbadabba.com/warranty

